

SAFE WORK PRACTICES



This project has been funded with support from the European Commission. This publication reflects the views only of the author, and the Commission cannot be held responsible for any use which may be made of the information contained therein.

Project No. 540447-LLP-1-2013-1-ES-LEONARDO-LMP

Depending on the legislation and the **specific work situation**, you should consider the following precautions:



Close the work area, restrict access and place warning signs.



Do not eat, drink and smoke at the workplace!



Use respiratory protection equipment with P3 class filter.



Use protective overalls, with hood tightly fitting to the face, ankles and cuffs, as well as rubber footwear and gloves.



✓ Moisten asbestos containing materials with water at low pressure.

✓ Disassemble materials carefully and avoid mechanical destruction methods.

Provide written instructions for carrying out the work and apply the necessary organizational measures!



Clean the site and tools by methods that do not spread dust, such as vacuum equipment with HEPA filter.

- Do not sweep by hand.
- Do not use compressed air or high pressure water.



Install decontamination chambers separating:

1. Dirty area (contaminated)
2. Intermediate zone (with showers)
3. Clean area (asbestos free)



Place the removed materials immediately into plastic package (double bag), label and deliver them to an authorized company.



In case of working with friable materials:

- ✓ Build work areas with units to maintain negative pressure and intercept dust emissions by HEPA filters
- ✓ Inject encapsulant product

**IN CASE OF DOUBT,
PLEASE ASK ASBESTOS
AWARENESS OFFICER**